



# CENTRALE AC134HD – MEMO D'UTILISATION

## Panneau de commande




N°	IDENTIFICATION	FONCTION
1	Ecran	Affichage des menus et fonctions
2	Touches numériques	Edition des valeurs
3	Touche <b>ENTER</b>	Validation de menu, de fonction ou de valeur
4	Touche <b>▲</b>	Défilement d'une liste vers le haut
5	Touche <b>▼</b>	Défilement d'une liste vers le bas
6	Touche <b>STOP / C</b>	Arrêt d'une fonction, correction et retour pendant la programmation Pressée durant 3 secondes : Interruption et retour à l'écran d'accueil
7	LED <b>RF</b> ◀	Signal de phase de récupération/recyclage
8	LED <b>VAC</b> ◀	Signal de phase de tirage au vide
9	LED <b>RF</b> ▶	Signal de phase de charge en réfrigérant

## Architecture des menus



# SERVICE UNIT AC134HD – QUICK GUIDE

## Control panel



N°	IDENTIFICATION	FONCTION
1	Screen	Menus and functions display
2	Keypad	Editing quantities / values
3	ENTER Key	Validation of menu, function or quantities
4	▲ Key	Scroll up
5	▼ Key	Scroll down
6	STOP / C Key	Stop a function, correct and return during programming. <b>Press for 3 seconds interrupts and reboot the unit.</b>
7	LED RF	Signals recovery stage
8	LED VAC	Signals vacuum stage
9	LED RF	Signals refrigerant charge stage

## Menu's overview

